


TARA SAFETY COVERS

BUCKLE THREADING INSTRUCTIONS


For complete safety cover installation guides go to www.taracovers.com



1 To thread a buckle, first start by feeding the end of the strap through the buckle.



2 Take the end of the strap and feed through the spring's end.



3 Feed the strap up through the buckle from the bottom side.



4 Bring the end of the strap back away from the pool cover.



5 Pull the loose end of the strap to tighten.

*The distance between the edge of the cover and the spring should be 10". The distance can be adjusted later if needed.